


Sizing Guide

Stabil-Air - 7.5 & 10 cm cell height



Item no. ESSA3 and ESSA4...	Base (C x D) Width x Depth (cm)	Cells (A x B) Width x Depth	Seat width* (cm)	Seat Depth** (cm)
...0909-1	26 x 26	5 x 5	22 - 25	24 - 27
...0911-1	26 x 30	5 x 6	22 - 25	28 - 31
...0913-1	26 x 34	5 x 7	22 - 25	32 - 35
...1109-1	30 x 26	6 x 5	26 - 30	24 - 27
...1111-1	30 x 30	6 x 6	26 - 30	28 - 31
...1113-1	30 x 34	6 x 7	26 - 30	32 - 35
...1115-1	30 x 39	6 x 8	26 - 30	36 - 40
...1309-1	34 x 26	7 x 5	31 - 35	24 - 27
...1311-1	34 x 30	7 x 6	31 - 35	28 - 31
...1313-1	34 x 34	7 x 7	31 - 35	32 - 35
...1315-1	34 x 39	7 x 8	31 - 35	36 - 40
...1317-1	34 x 44	7 x 9	31 - 35	41 - 45
...1511-1	39 x 30	8 x 6	36 - 40	28 - 31
...1513-1	39 x 34	8 x 7	36 - 40	32 - 35
...1515-1	39 x 39	8 x 8	36 - 40	36 - 40
...1517-1	39 x 44	8 x 9	36 - 40	41 - 45
...1519-1	39 x 49	8 x 10	36 - 40	46 - 50
...1521-1	39 x 53	8 x 11	36 - 40	51 - 55
...1713-1	44 x 34	9 x 7	41 - 45	32 - 35
...1715-1	44 x 39	9 x 8	41 - 45	36 - 40
...1717-1	44 x 44	9 x 9	41 - 45	41 - 45
...1719-1	44 x 49	9 x 10	41 - 45	46 - 50
...1721-1	44 x 53	9 x 11	41 - 45	51 - 55
...1915-1	49 x 39	10 x 8	46 - 50	36 - 40
...1917-1	49 x 44	10 x 9	46 - 50	41 - 45
...1919-1	49 x 49	10 x 10	46 - 50	46 - 50
...1921-1	49 x 53	10 x 11	46 - 50	51 - 55
...2115-1	53 x 39	11 x 8	51 - 55	36 - 40
...2117-1	53 x 44	11 x 9	51 - 55	41 - 45
...2119-1	53 x 49	11 x 10	51 - 55	46 - 50
...2121-1	53 x 53	11 x 11	51 - 55	51 - 55

...For the complete item number, see related product sheet.

Stabil-Air - 7.5 & 10 cm cell height

Stabil-Air cushions with a cell height of 7,5 & 10 cm have a cell diameter of 5 cm.

The base is approximately 2 cm wider on all sides (E), than the measurement from outer cell to outer cell (A and B)

The cushion base measurements (C x D) are indicated in all documentation.

***Seat width:** If placed on a wheelchair, the cushion base edges (E) may fold upwards. One cushion size fits to a seat width range of 3-5 cm.

****Seat depth:** The seat depth is measured at the middle of the seat, from the front edge to the back upholstery. The measurement should be taken when the back upholstery is adjusted correctly. Place the cushion as far back on the seat as possible.

Etac

+46 371 587 330

info@etac.se

www.etac.com